



— ENVOY 2 S SERIES QUICK START —

Hold  to turn **ON**. LED will turn on, the player will “beep” *once* and play automatically. Hold  again to turn **OFF**. LED will turn off, the player will “beep” *twice* and stop playing.

Problems with the player? Try pressing the Reset button.



**Envoy 2 S Dual Pictured*

SECTIONS/
CHANNELS



SECTIONS/
CHANNELS



VOLUME



PAUSE/
BOOKMARK



SECTIONS (Click)/
CHANNELS (Press)



BOOKS



CHAPTERS



VERSES



Full user manual: <https://kvisit.com/VQ/ueC0AQ/BQ>

