

ENVISION C01

Quick Start Guide



Full user manual:

<https://kvisit.com/VQ/ueC0AQ/CA>

Secure, Accessible, Touch Screen Audio/Video Device

Perfect for visual learners and those who are deaf or hearing-impaired.

- 1 Power Button
*Press and hold for 2 seconds to turn **ON**.
Press and hold again for 2 seconds to turn **OFF**.*
- 2 3.5mm Stereo Audio Jack
- 3 Audio/Visual Connector
- 4 MicroSD Card Reader
- 5 Type-A USB OTG Connector
- 6 Type-C USB Charge and Data Connector
- 7 Red/Green Charge LED
- 8 Hardware Reset Switch



ENVISION C01

Quick Start Guide



Full user manual:

<https://kvisit.com/VQ/ueC0AQ/CA>

- 1 Volume/Brightness Sliders
- 2 Charge Indication (fully charged)
- 3 Battery Capacity (full)
- 4 Volume Adjustment (active)
- 5 Brightness Adjustment
- 6 Internal Storage (selected)
- 7 MicroSD (connected)
- 8 OTG (connected)
- 9 A/V Device (connected)
- 10 Go to Images
- 11 Go to Audio
- 12 Go to Videos
- 13 Go to Documents
- 14 Go to Storage Selection
- 15 Go to Device Info



Image Above: Envision C01 is connected for charging (completed) (2), battery is full (3), an external audio device is connected (4), A/V device is connected (but not active) (9), the volume is being adjusted (1+4), and external microSD and OTG are connected (7+8) but Internal Storage is the selected input (6).